

# LIGHTHOUSE PRO XLS™

## 8-Outlet Power Bar

### Instructions

1. **IMPORTANT:** Disconnect power on the Lighthouse Pro before connecting the Power Bar!
2. Attach the small end of the included USB cable to the Power Bar.
3. Connect the other end of the cable to the console. If you already have a Power Bar installed, connect the new Power Bar to connector #2. If only one Power Bar is being used, use connector #1.
4. Power up the Lighthouse Pro. The unit will scan for new hardware and add the new Power Bar to the system.

### Notes

To manually control outlets on a second Power Bar, press the *2ND* button on the remote followed by one of the number buttons (1 – 8). The corresponding outlet will toggle on and off.

Once properly installed, the console web pages and front panel display will automatically be expanded to show the additional outlets available.

It is essential to disconnect power when attaching Probe Modules, Temperature Sensors, or AC Power Bars. This is because the unit searches for new hardware only during the power up sequence.

**WARNING:** Hazardous voltages inside. Do Not Open. Opening void warranty.

